# **IDEAL 4606**

Compact high-capacity shredder with automatic oiler and feeding hopper for crumpled paper. Provides data security for an entire office floor.

Level P-3 6 x 50 mm particle cut

Sheet capacity\*: 85-95 | 74-83

Level P-5 2 x 15 mm particle cut

Sheet capacity\*: 35-45 | 30-39





← 46 cm →

\* A4 paper 70 g/m² | 80 g/m²

# Technical specifications

Volume	230 litres (mobile shred bin)
Power	400 V / 50 Hz / 3 ~**
Motor capacity	2.2 kW three phase motor

\*\* other voltages available



Dimensions	1700 x 740 x 765 mm (H x W x D)
Weight	253 kg

## Product characteristics

Tilting feeding hopper for crumpled paper. Feeding paddle for effective insertion of crumpled paper into the cutting head. Second feed opening (460 mm) located under the hopper for flat paper and computer printouts with automatic start/stop via a photo cell. EASY-SWITCH – intelligent multi-function control element indicating the operational status of the shredder with varying colour codes and back-lit symbols. Electronic control prevents overfeeding: automatic reverse and refeeding in case of paper jams. Fold-away feeding table. Main switch and emergency cut-off switch. Robust shredding heads with special hardened cutting shafts made of high-quality steel, resistant against soft metal objects. Automatic oil injection on the cutting shafts during shredding operation for constantly high shred performance. Automatic standby after 30 minutes. Powerful three phase motor with thermal motor protection. Front door and mobile shred bin for easy removal of the full shred bag. High volume container for the shredded material. Automatic stop when hopper or front door is opened, or when the shred bin is full. Mobile on castors. Two years guarantee on the cutting tools.





# **IDEAL 4606**

#### **Features**



#### **EASY-SWITCH**

Ease of operation: intelligent multifunction switch element with integrated optical signals indicating the operational status.



#### **FOLD-AWAY FEEDING TABLE**

The fold-away feeding table is ideal for inserting flat paper. A photo cell automatically starts and stops the cutting head when using this feed opening.



## **FEEDING HOPPER**

Should a paper jam occur, the electronically secured feeding hopper can be tilted for safe and convenient clearing.



#### **FEEDING PADDLES**

Crumpled paper is fed into the shredding unit by rotating rubber paddles in the feeding hopper of this shredder model.



#### **ELECTRONIC OIL INJECTION**

The automatic oil injection system lubricates the cutting shafts when shredding and guarantees a constantly high shred performance.



#### **MOBILE SHRED BIN**

The shred bin on castors is easily removable through the front door. The shredder stops automatically if the door is opened.















